

ULTIMATE GUIDE TO

Vehicle Lift Installation



Installing your car or truck lift the right way (not to mention safely) takes some pre-planning.

But with the right amount of preparation, tools and several extra hands, you can install your new lift in no time.

Of course, having your lift installed by a Rotary Authorized Installer also has its advantages. Don't overlook all of the benefits that come with having your lift installed for you. More to come on that!

Select a Location

- Check your lift's dimensions against the architect's plans for your shop, if possible. You definitely don't want to purchase, assemble and begin installation on a lift that is too large for the space you have.
- Remember: Space to install the lift isn't enough. You also need the space to operate the lift safely.
- Don't plan on installing in an area where there isn't adequate overhead clearance. Your space should be free of lights, electrical lines, heaters and architectural elements above the lift.
- Ensure that an electrician will have easy access to a 220-volt, 30-amp, single-phase, grounded electrical source.

Flooring

- Don't install your lift on any surface other than concrete.
- Concrete must be reinforced to a minimum of 3,000 PSI and follow the thickness guidelines for the specific lift you're installing.
- Your intended location should have a good, solid foundation. Check for cracks or defects in the concrete before you begin installation.
- We recommend that your floor be as close to level as possible. You can always
 use shims to achieve a perfectly level lift, but that adds another element to
 your installation.
- If you pour new concrete to attain a level surface, allow a minimum of 30 days before installation so that the concrete can adequately cure.
- Don't install your lift outdoors without taking precautions to protect the power unit from the elements.

Initial Assembly

- Before beginning assembly, read the instructions carefully. While the assembly steps aren't necessarily difficult, a lift is an expensive, heavy and potentially dangerous piece of equipment. You don't want to lose your investment or cause injury due to taking a shortcut.
- When assembling the structure, keep everything square and aligned.
- Initially, tighten the bolts by hand. Then, finish by torqueing to the specifications in the instructions.
- Assemble the equalizer cables, hydraulics and arm restraints while the lift is still lying on the ground.

Final Assembly

- Raising the lift will take a minimum of six people. If your lift is intended for heavier vehicles, it may take as many as ten.
- Use an SDS-max rotary hammer to start the holes for the mounting hardware. Then, use a masonry bit to drill through the concrete completely. (Always wear safety gear.)
- Use the included or recommended wedge anchors and torque to specs.
- Columns should be 90 degrees. Level with shims if necessary.
- Hire a licensed electrician to install power.
- Inspect every aspect of the lift before use—safety mechanisms, hydraulics, cables, everything.

Leave it to the pros

While you can certainly install your new lift without a Rotary Authorized Installer (RAI), it's a lot easier and more beneficial if you don't go it alone. When you do choose to use a RAI, you get these guarantees:

Parts. RAIs only use Genuine Rotary Parts during the installation and for service.

Parts warranty. Two-year warranty on parts (with the option of buying three more years).

Installation. One-year warranty against faulty materials or workmanship.

Insurance. RAIs are fully covered with both general liability insurance and product/operations insurance, which means you're protected even after the RAI leaves your shop.

On-site training. Your techs receive full training on the new lift before the RAI leaves your shop.

Inspections. Many RAIs are certified to inspect lifts by the Automotive Lift Institute and can conduct inspections upon request or on a regularly scheduled basis.

To find a Rotary Authorized Installer near you, simply visit our site at RotaryLift.com/Support-RAI.



