

# SG-2 & SG-3 Air Gauge Re-Calibration Procedure



1. Use a slotted screw driver to turn the adjustable calibrating screw at the bottom of indicator bar.
2. If gauge is reading too low, turn screw clockwise approximately ONE turn for each pound it reads low. If gauge is reading too high, turn screw counter-clockwise approximately ONE turn for each pound it reads high.
3. Check reading after adjusting the screw.
4. Repeat procedure if needed.