

6400 Adapter Kit

Bolt Centric Truer Adapters

(A1 – A5)



A1 - 6362 (5 Lug Metric)

- 1:5 – 100mm
- 2:5 – 110mm
- 3:5 – 115mm
- 4:5 – 120mm
- 5:5 – 130mm
- 6:5 – 135mm



A2 - 6381 (5 Lug Imperial)

- 1:5 – 4.00"
- 2:5 – 4.25"
- 3:5 – 4.50"
- 4:5 – 4.75"
- 5:5 – 5.00"
- 6:5 – 5.50"



A3 - 6364 (6 Lug Metric)

- 1:3 – 115mm
- 2:3 – 120mm
- 3:3 – 132mm
- 4:3 – 135mm



A4 - 6382 (6 Lug Imperial)

- 1:3 – 3.50"
- 2:3 – 4.00"
- 3:3 – 4.50"
- 4:3 – 5.00"
- 5:3 – 5.50"
- 6:3 – 6.00"
- 7:3 – 7.00"



A5 - 6366 (Various SUV 4 & 5 Lug)

- 1:2 – 3.937" (100mm)
- 2:2 – 4.25" (108mm)
- 3:5 – 4.409" (112mm)
- 4:2 – 4.50" (114.3mm)
- 5:5 – 5.906" (150mm)



A6 - 6367 (81-10 Lug P/U)

- 1:4 – 6.56" (165.1mm)
- 2:4 – 6.69" (170mm)
- 3:4 – 7.086" (180mm)
- 4:4 – 8.25" (209.5mm)
- 5:4 – 8.858" (225mm)
- 6:3 – 8.858" (225mm) for 10 lugs