



### Replacement Parts list

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
1.	12910B2	Air Tank ( 3L, 6L, 10L )
2.	12913B2C	Slotted Barrel w/ 2" Connector
3.	12912B2	( 50.8 mm ) 2" Lock Nut
4.	12950	2" W 1.7 O-Ring
5.	12951	2" Wide Screw
6.	12952	2" W 5.3 O-Ring
7.	12953	2" Piston-L40mm
8.	12954	2" W 3.5 O-Ring
9.	12955	Stainless Spring
10.	12956	2" W 11.2 O-Ring
11.	12919BS	Safety Trigger Caps
<b>12.</b>	<b>12919B</b>	<b>Switch Valve</b>
13.	12920B	Grip-BB
14.	12921B	Plastic Plug
15.	12914B	1.5" Pressure Gauge -10Bar
16.	12917B	CE Safety Valve -Max 10Bar
17.	12930M	F ¼" x3 & M ¼"x1 Connector
18.	12916B	( 6.35 mm ) ¼"PT Intake Valve
19.	12927	Universal Connector

**CAUTION:**

- It is best to use clean / filtered compressed air to fill all Bead Bazooka® / Bead Booster® inflation tools.
- Unfiltered or unclean compressed air may result in poor performance and shorten the life of the product.
- Gaither recommends this Bead Bazooka® tank be replaced after 5 years.
- When not using , Please put the Safety Trigger Caps back onto the Switch Valve