


Chassis System

Item	Part No.	Description
**1	80004911	Lube Applicator
**2	81062591	Lube Bottle (Red)
3	8106301	1/4" Hex Hd Self Tap Screw, Gr.5
**4	8182809	Lube Bottle Bracket
5	8182811	Inflation Pedal Cover
6	8181285	Inflation Pedal Decal
7	85607585	Metal Side Panel
8	8182040	M10-1.5 x 55MM Hex Hd.Cap Scr, Gr.8.8
9	8301032	3/8 Flat Washer, Zinc Plate
10	8107715	3/8-16 x 1-1/4 Hex Hd. Cap Scr, Gr.5
11	8181964	Plastic Accessory Tray
	85608840	Plastic Accessory Tray for Air Nozzle
12	8183770	Lubricator Bracket
13	8183778	Lubrication Notice Decal
14	8182579	3/4 x 5 Grade 5 bolt
15	85612239	Water Separator Assy (Air Motor Machines Only)
16	8182016	5/8-11 Hex Nut
17	85611555	Chassis

Item	Part No.	Description
19	8182088	5/16-18 x 1-1/4 TPHST Screw, Gr.5
20	8181855	B.L. Pad
**21	8181354	Bead Lifting Tool (Optional on Leverless Unit)
**22	85000783	Lift Tool Bootie Kit, Pkg of 10
23	924724	312-18 Hex Flange Nut
24	856104041	Tank Reservoir w/Cap
25	81856301	Tank Reservoir Cap, Red Push-On St
	8561040601	Tank Reservoir Cap Black Screw-On Style
26	8183452	5/16-18x5/8 HWHCS Screw
**27	85000850	Tire Paste Brush
**28	81837101	Universal Mounting Paste
**29	85009048	Lube Bucket Bracket & Brush Kit
30	85608894	Inflation Nozzle Cone
31	85611051	Washer
32	8104573	3/4" Straight Fitting
33	85610108	Plug, 1" Dia.
34	8101346	Clamp-Hose, 1/2 X 1-1/4
35	85611051	Bushing-Nylon Dia. 1.5
36	85610631	Cover Assembly

**Accessory



APPLY GREASE TO THESE LOCATIONS