



Robo-Arm® LR Assembly




● Apply Grease To These Locations


Valve Assemblies




**Robo-Arm® LR
Valve Assembly**




**Bead Loosener Arm Pedal
Valve Assembly**



**Air Motor Pedal
Valve Assembly**



**Table Top Clamp Pedal
Valve Assembly**



**Table Top Clamp Pedal
Valve Assembly**

Item	Part No.	Description	Item	Part No.	Description
2	8000378	1/4" Brass St. Fitting	12	8184467	1/4" NPT x 3/8 BRB x 3/8B Tee Fitting
6	8105615	Small Muffler	14	8181986	4-Way w/Pull Pin Valve
7	8185585	3 Position Valve	15	906960	1/4 NPT Muffler
8	8109481	1/4 NPT x 1/8 NPT RDCR Fitting	16	8184256	1/4 NPT, 1/4 HSE ELL Fitting
9	8181997	90° Elbow 1/8 NPT x 1/8" Fitting			
10	8101898	St. 1/4" NPT 3/8" Hose Fitting			
11	8184369	4-Way w/Pull Pin Valve			