




Accessories

#	Part Number	Description
1601		Truck Spacer Cone (40mm); RB30T
1602		Wheel Lock Kit Weldment; RB30T
1603		165-215mm CONE; RB30T(40mm)
1604		Spacer Ring #2; RB30T
1605		140-171mm CONE; RB30T(40mm)
1606		98-150mm CONE; RB30T(40mm)
1607		CONE; RB30T(40mm)
1608		Jaw Chuck Cone#2; RB30T
1609		Jaw Chuck Cone#3; RB30T
1610		Jaw Chuck Cone#4; RB30T
1611		Motor Belt
1612		Allen Wrench; 3mm
1613		Allen Wrench; 5mm
1614		Allen Wrench; 6mm
1615		Allen Wrench; 8mm
1616		Allen Wrench; 10mm
1617		Allen Wrench; 16mm
1618	5346425	Weight Pliers
1619		100G Calibration Weight
1620		200G Calibration Weight
1621		Quick nut 40mm
1622		Reverse bowl rubber ring
1623		Reverse bowl
1624		Small Reverse bowl
1625	5328286	Black lead block shovel

Accessories Cont.

#	Part Number	Description
1626		Taper spring
1627		SHCS M10X20
1628	5346002	Calipers
1629		Machine expansion bolts
1630		Spacer Ring #1 ; RB30T
1631		Position shaft
1632		SHCS M8X40
1633		Position shaft2
1633		Position plate3
1634		Plate core
1635		Washer; ø8 flat
1636	5545340	Nut M16
1637		Washer; Ø16 flat
1638		Washer; Ø16 Spring
1639		Truck Spacer Cone (40mm); RB30T