

8 Spare parts list

Ref.No.	Pos. Drawing	Qty	Description
564	1	1	Housing RC 414, red, with carrying handle
0510	1	1	Housing RC 314, red, with carrying handle
	6	1	Switch button
564	5	1	Transformer RC 414/314, 230-240V, incl. base plate
0520	5	1	Transformer RC 414/314, 115V, incl. base plate
564	4	1	Rotary switch
0128			
564	3	1	Cable for cutting head, RC 414, complete
0460	3	1	Cable for cutting head, RC 314, complete
			Handle assembly, comprising:
564	2	1	Right half of handle
0530		1	Left half of handle
	20		Cutting head assembly, comprising:
	12	1	Cutting head right
5640860	11	1	Cutting head left
	16	2	Slot nut
	30		Set of clamping jaws, comprising:
	14	1	Clamping jaw, right
5640820	13	1	Clamping jaw, left
	16	2	Slot nut
	17	2	Hex. socket screw M4 x 15
			Set of screws, comprising:
5640870	40	8	Plastic parts
		2	Cylinder head screw M4x10, switch
		2	Threaded pin M5 x 6

