

8 Spare parts list

Ref.No.	Pos.	Drawing	Qty	Description
564	1		1	Housing RC 414, red, with carrying handle
0510	1		1	Housing RC 314, red, with carrying handle
	6		1	Switch button
564	5		1	Transformer RC 414/314, 230-240V, incl. base plate
0520	5		1	Transformer RC 414/314, 115V, incl. base plate
564	4		1	Rotary switch
0128				
564	3		1	Cable for cutting head, RC 414, complete
0460	3		1	Cable for cutting head, RC 314, complete
				Handle assembly, comprising:
564	2		1	Right half of handle
0530			1	Left half of handle
	20			Cutting head assembly, comprising:
	12		1	Cutting head right
5640860	11		1	Cutting head left
	16		2	Slot nut
	30			Set of clamping jaws, comprising:
	14		1	Clamping jaw, right
5640820	13		1	Clamping jaw, left
	16		2	Slot nut
	17		2	Hex. socket screw M4 x 15
				Set of screws, comprising:
5640870	40		8	Plastic parts
			2	Cylinder head screw M4x10, switch
			2	Threaded pin M5 x 6

