

U.W.T. INSTRUCTIONS

TO REMOVE WHEEL WEIGHTS USING UWT HAMMERS AND SIDEKICKS FROM STANDARD WHEELS AND TIRES (GO DIRECTLY TO STEP 2)

STEP 1- TO REMOVE WHEEL WEIGHTS USING UWT HAMMERS AND SIDEKICKS FROM WHEELS OF TIRES WITH CURB PROTECTORS
HOLDING UWT HAMMER BY THE T-HEAD INSERT THE HOOK FLAT BETWEEN THE CURB PROTECTOR AND WHEEL WEIGHT CLIP AT WHEEL WEIGHT HOLE AND TURN T-HEAD. (PHOTO #1 & #2)

STEP 2- USING UWT HAMMER OR SIDEKICK INSERT HOOK INTO WHEEL WEIGHT CLIP HOLE. (PHOTO #3 & #4)

STEP 3- GENTLY PULL HANDLE TOWARDS CENTER OF WHEEL WHILE REMOVING WHEEL WEIGHT. (PHOTO #5)



PHOTO #1



PHOTO #2



PHOTO#3



PHOTO #4



PHOTO #5

TO TURN DOUBLE ENDED HOOKS: USING A 3/16 HEX/ALLEN WRENCH REMOVE CAP SCREW FURTHEST FROM THE END OF THE HOOK AND SLIGHTLY LOOSEN REMAINING CAP SCREW. ROTATE HOOK 180 DEGREES. RE-INSTALL SCREW AND RE-TIGHTEN BOTH SCREWS (DO NOT OVER TIGHTEN) (PHOTO #6 & #7)

TO REPLACE VALVE CORE REMOVER: USING A 5/64 ALLEN HEX ALLEN WRENCH REMOVE SET SCREW. REMOVE VALVE CORE TIP & REPLACE. RE-INSTALL SCREW AND TIGHTEN. (DO NOT OVER TIGHTEN) (PHOTO #8 & #9)



PHOTO #6



PHOTO #7




PHOTO #8



PHOTO #9

FOR A MORE DETAILED INSTRUCTION VIDEO VISIT OUR WEBSITE AT: WWW.UWTINC.COM

AVAILABLE ACCESSORIES AND REPLACEMENT PARTS AND PRODUCT WARRANTY (SEE REVERSE SIDE OF THESE INSTRUCTIONS)

AVAILABLE TOOLS, ACCESSORIES AND REPLACEMENT PARTS

<u>PART #</u>	<u>DESCRIPTION:</u>	<u>NOTES:</u>
UWT1000	HAMMER & WHEEL WEIGHT REMOVER	TOOL FOR REMOVAL AND APPLICATION OF WHEEL WEIGHTS (USE WITH HOOKS #5, #6 OR #7)
UWT2000	SIDEKICK W/DOUBLE HOOKS	TOOL FOR REMOVAL OF WHEEL WEIGHTS (USE WITH HOOKS #5, #6 OR #7)
UWT3000	SIDEKICK W/CORE REMOVER & DBL HOOK	TOOL FOR REMOVAL OF VALVE CORES & WHEEL WEIGHTS (USE WITH HOOKS #5, #6 OR #7)
UWT1000-3	UWT PROTECTOR REPLACEMENT CAP	REPLACEMENT PART (FOR USE WITH UWT 1000 HAMMER HEAD)
UWT3000-2	CORE REMOVER REPLACEMENT TIP	REPLACEMENT PART (FOR USE WITH UWT 3000)
UWT9000-1	HEEL PLATE	ACCESSORY THAT ASSIST'S WITH REMOVING .25 & .50 OZ. CLIP ONLY STYE WHEEL WEIGHTS.
UWT9000-2	1/4-28 x 1/2 SOCKET HEAD CAP SCREW	REPLACEMENT PART (FOR USE WITH ALL UWT TOOLS)
UWT9000-3	8-32 x 5/16 SET SCREW	REPLACEMENT PART (FOR USE WITH UWT 3000)
UWT9000-52	#5 TWO HOLE REPLACEMENT HOOK	REMOVES THE MAJORITY OF ALL WHEEL WEIGHTS
UWT9000-52	#5 THREE HOLE REPLACEMENT HOOK	" "
UWT9000-62	#6 TWO HOLE REPLACEMENT HOOK	SPECIALTY HOOK – REMOVES STUBBORN MC &AW LEAD WHEEL WEIGHTS
UWT9000-63	#6 THREE HOLE REPLACEMENT HOOK	" "
UWT9000-72	#7 TWO HOLE REPLACEMENT HOOK	SPECIALTY HOOK – REMOVES IMPORT O.E. AND IMPORT AFTER MARKET WHEEL WEIGHTS
UWT9000-73	#7 THREE HOLE REPLACEMENT HOOK	" "

U.W.T. INC. LIFETIME WARRANTY

U.W.T. Inc., tools are warranted against defects in materials and workmanship for the life of the product. Hooks and replacement hooks have No-Warranty. These warranties do not apply to items that have been misused, abused, altered in any way, or worn out from use. U.W.T. Inc. makes no other warranties with respect to our products or their suitability for specific applications.

U.W.T. Inc. will at its option, provide repair parts, repair or replace any tool deemed defective. Warranty applies to individual parts on the tool. At our discretion if one part is deemed defective we will replace or repair that part and not the entire tool.

All claimed defective tools must be returned to the place of purchase or U.W.T. Inc., for replacement at the buyers or distributors expense. In cases where there is a question regarding defective or abused tools, the tool will be returned to U.W.T. Inc., for a determination. After a determination is made we will credit, replace or repair the tool at our option. Tools that have been ground, filed, welded, hammered or modified in any way, are not covered under the U.W.T. Inc's, Lifetime Warranty.

U.W.T. Inc. shall not be liable for any consequential or incidental damages incurred by the purchaser. Buyer's sole and exclusive remedy for any loss incurred shall be a refund of the selling price.

The exclusive remedy for any product found to be defective under the above warranties is limited to the repair or replacement of the defective product without charge. U.W.T. Inc., shall not be liable for any consequential or incidental damages, including labor charges.

FOR MORE INFORMATION VISIT OUR WEBSITE AT: WWW.UWTINC.COM OR CALL 336-537-4048 U.W.T PRODUCTS ARE MADE IN THE U.S.A